

PORTABLE D.A.T.
The Basic 'Need to Know' Guide

SET-UP

- REMEMBER – there is no 'ON/OFF' switch.
Batteries 'IN' = *ON*, Batteries 'OUT' = *OFF*
- If needed, you can use DC power when near a power point.
- Switch on the microphone and plug into the red jack socket on D.A.T.
(*REMEMBER – On silver D.A.T. slide needs to be set to MIC not LINE-IN when recording.*)
- Plug headphones into green jack socket.
- Insert tape (open by sliding catch on side of D.A.T. machine).
- Now check switches on the D.A.T.

MIC SENS – Set to '*H*'.
REC MODE – Set to *MANUAL* and adjust accordingly.

Remember to select *STD not LONG* play and record at 44.1kHz.

HOW TO RECORD & PLAYBACK

- Press RECORD. Then press PAUSE.
- Set levels.
- To begin recording press PAUSE again.
- When you have finished recording press PAUSE or STOP.
- To listen back press REWIND and then PLAY. Sound will come through headphones. You can adjust headphone volume if necessary.